### BELKIN.

### Self Help Guide

### **IMPORTANT!**

### Before you begin

#### You will need:

- Belkin VoIP unit
- Power cable
- Network cable


#### Hardware check:

- Your computer is switched on
- The VoIP unit is switched on (power switch at rear)
- Network cable connected from computer to the VoIP unit


#### Upgrade the firmware on your Belkin ATA

This process may take up to 1-2 minutes

- Step 1 Open the ATA Discovery Tool (located on CD provided with ATA)
- **Step 2** The Discovery Tool should find the ATA, highlight the listing then click **Open**



- Step 3 The Login page should appear. Type in your current password (default password = admin) then click LOGIN
- Step 4 On the left hand side of the screen click Advanced Setup
- Step 5 You will now be presented with more options in the menu on the left. Click Utilities then choose Firmware Update



- Step 6 Click the browse button, located in the centre of the screen
- Step 7 You will now be presented to browse for the file downloaded earlier in step two. Browse to the file and click Open




F1PG200ENau

## BELKIN<sub>®</sub>


## Self Help Guide



Step 8 Click Update, two warnings will now appear, click OK on each



Step 9 Once the Firmware Update process has completed, you will need to restart the ATA by clicking the Restart ATA button



# BELKIN.

# Self Help Guide

